2 sec = OFF




Transportation



User Manual:


www.leica-geosystems.com




- when it has to be **right**


Leica Geosystems

Adapter setup






Usable with UAL 130




Usable with Receiver



Quick Start

Leica Lino L2P5G




- when it has to be **right**

Leica Geosystems


Insert batteries/Li-Ion




1x - Laser on



3x - Vertical mode




Charging Li-Ion battery




Self levelling / Levelling lock



2x - Horizontal mode



+ 1× — + 1× |



Status LED



- Normal operation
- Instrument locked
- Low battery
- Out of level